

## プログラム再生時の注意事項について

### CD-601MKII/RC-601MKII 共通

プログラム再生モードでキューポイントが登録されている場合、停止時に READY キーを押すと、再生モードが通常再生（全曲再生）に自動的に切り換わり、キューポイントにロケートしてオンライン READY になります。

ただし、モニター再生中に READY キーを押すと、再生モードはプログラム再生のままにキューポイントにロケートしてオンライン READY になります。

### RC-601MKII 使用時

プログラム再生モードでキューポイント（CUE1～CUE10）へのロケート操作を行なうと再生モードが通常再生（全曲再生）に自動的に切り換わり、キューポイントにロケートします。

ロケート後の待機状態はオートキューアップ設定（メニュー番号 16 で設定）に従ってオンライン READY またはモニター PAUSE になります。

プログラム再生モードでフラッシュスタートを行なうと再生モードが通常再生（全曲再生）に自動的に切り換わり、フラッシュスタートを開始します。

プログラム再生モードでテンキーによるトラックスキップを行なうと再生モードが通常再生（全曲再生）に自動的に切り換わり、テンキーで指定したトラックにスキップします。

プログラム再生モードではタイムサーチができません。タイムサーチ機能がオンのときにプログラム再生モードに設定すると、タイムサーチ機能が自動的に解除されます。

プログラム再生モード時は、メモポイントを使った機能を使うことができません（メモポイントの設定、ロケートはできます）。また、メモモード中はプログラム再生モードにすることができません。

## Precautions during Program Playback

### When using both the CD-601MKII/RC-601MKII

- When the cue point has been registered in the program playback mode, and the READY key is pressed while the disc operations are stopped, the playback mode automatically switches to regular playback (all tunes playback), and the CD-601MKII is located to the cue point and enters the online READY mode.

Note, however, that when the READY key is pressed during monitor playback, the CD-601MKII/RC-601MKII is located to the cue point in the program playback mode stays as it is, and enters the online READY mode.

### When using the RC-601MKII

- When locating the cue point (CUE1 to CUE10) is performed in the program playback mode, the playback mode automatically switches to regular playback (all tunes playback), and the CD-601MKII is located to the cue point. After the cue locate, the standby state becomes the online READY mode or the monitor PAUSE mode by setting the auto cue up (set in the menu No. 16).
- When the flash start is performed in the program playback mode, the playback mode automatically switches to regular playback (all tunes playback), and the flash start is begun.
- When the track skip is performed using the numeric keys in the program playback mode, the playback mode automatically switches to regular playback (all tunes playback), and the CD-601MKII skips to the track selected by the numeric keys.
- The time search function does not work while in the program playback mode. When the time search function is ON, changing the mode to the program playback mode automatically cancels the time search function.
- In the program playback mode, functions using the memo point cannot be used. However, setting the memo point is available as well as its locating.  
The CD-601MKII/RC-601MKII cannot be set to the program playback mode while the memo mode is active.

### CORRECTION

In the Owner's Manual of the CD-601MKII, Important Safety Precautions (see page 2), unfortunately the CE Marking Information b) was incorrect. The peak inrush current is 12A (not 2.5A).