TASCAM IF-AN/DM Reference Level Setting
(-16dB = default)

Analog Input

	CH-1		CH-2		CH-3		CH-4	
Ref. Level	SW 011	SW 021	SW 012	SW 022	SW 013	SW 023	SW 014	SW 024
-11dBFS	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
-16dBFS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
-20dBFS	ON	ON	ON	ON	ON	ON	ON	ON

	CH-5		CH-6		CH-7		CH-8	
Ref. Level	SW 015	SW 025	SW 016	SW 026	SW 017	SW 027	SW 018	SW 028
-11dBFS	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
-16dBFS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
-20dBFS	ON	ON	ON	ON	ON	ON	ON	ON

Analog Output

	CH-1		CH-2		CH-3		CH-4	
Ref. Level	SW 031	SW 041	SW 032	SW 042	SW 033	SW 043	SW 034	SW 044
-11dBFS	ON	ON	ON	ON	ON	ON	ON	ON
-16dBFS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
-20dBFS	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

	CH-5		CH-6		CH-7		CH-8	
Ref. Level	SW 035	SW 045	SW 036	SW 046	SW 037	SW 047	SW 038	SW 048
-11dBFS	ON	ON	ON	ON	ON	ON	ON	ON
-16dBFS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
-20dBFS	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF